

Barrier Removal	21	Low Battery Indicator	14
Battery Replacement.....	14	Normal Operating Colors.....	15
Before You Begin	6	Normal Operating Sounds.....	15
Child-Proof Feature.....	15	Power Outages	14
Direct Operation	8	Remote Control Warnings	6
Display Fahrenheit or Celsius	13	Remote Operation.....	10
Face Installation and Removal.....	20	Remote Set-Up	10
Glass Cleaning.....	24	Replacement Parts List.....	27
Glass Frame Removal and Installation	22	Starting the Fireplace for the First Time	9
Grill Installation and Removal	19	Troubleshooting Table	26
Installation Warnings.....	2	Wiring Diagram	27
Intermittent/Continuous Pilot.....	9	Yearly Service Procedure	16
Location of Controls	8		

Draft

Draft

Draft

Draft